


# Instruction Manual Pop-Up Fabric



1. Open the bag / trolley case and take out the Pop-Up frame



2. Place the frame in front of you with the label Frontside Top facing away from you



3. Open the frame slightly by pulling the hinges outwards

4. Place your hands on the bars as marked in the picture


5. Gently lift up the the frame, while ipping it over

6. The pop-up frame unfolds as you lift it up further

7. Push the frame outwards to completely open the frame

8. Check if all the clips are facing the opposite parts

9. Close all 16 clips to lock the frame



10. Place the frame on the ground with the white velcro up, for easy attachment of the print



11. The adjustable feet mark the bottom of the frame

12. Attach one corner of the fabric to the side of the frame (don't use Velcro on backside)

13. Stretch the fabric tight and go to the next corner

14. Work your way around the frame until all Velcro straps are attached

15. Lift the frame up again, the Pop Up Display Fabric is now ready to use

## Pop-Up Fabric 5x3

PUF53S

SKU	Dimensiones (mm) (A x B x C)	Orientación	Parte visible (mm)	Formato (mm)	Potencia (W)
PUF53S	3700 x 2240 x 300	Vertical	-	5 x 3 (3700 x 2240 mm)	-

Iluminación	Color de la iluminación (K)	Luminosidad (cd)	Intensidad de luz (lx)	Peso neto (kg)	Peso total
No	-	-	-	17,50	19,50

Anchura paquete (mm)	Altura paquete (mm)	Largura paquete (mm)	Numero de piezas por pallet	Peso del pallet(kg)	Tipo de pallet
590	390	970	8	180	EUR

Certificado del producto	EAN
-	8596052090837